### **DEFLECTOR KIT**

# MODEL # 60600

#### ASSEMBLY INSTRUCTIONS



L

Thank you for selecting EarthWay for your deflector needs. Our production team in Northern Indiana takes pride in building each and every product.

Our customer support team is standing ready to ensure your success. Please contact us at www.EarthWay.com to see our full line of lawn, garden, and professional tools.

#### ASSEMBLY HARDWARE – BY SPREADER MODEL

ALL MODELS	#12299 Front Panel	#12303 Side Panel	#60161 Frame	#12298 Panel Mounting Clips	#36201 ¼-20X3/4 Bolt	#363300 ¼-20 Locknut
			<	0		
ATTACH TO 90950 50LB SPREADER		#12304 Hopper Mounting Clamps	#3622 ¼-20X Screv	1 1/4-20	Hex	
ATTACH TO 2150, 90365, 90399 & 2170 MODELS		#12305 Hopper Mounting Clamps	#36210 %-20X	1 0 ½	3330 3-20 knut	

## **DEFLECTOR KIT**

### MODEL # 60600

#### ASSEMBLY INSTRUCTIONS



# **DEFLECTOR KIT**

# MODEL # 60600

#### ASSEMBLY INSTRUCTIONS

**Step 3:** Repeat step 2 with the other side panel.

**Step 4:** Select the front panel (the one with three holes). Follow the same process as in step one and insert three bolts and attach with three nuts.



#### TO ATTACH DEFLECTOR TO 90950 50LB ICE MELT SPREADER

**Step 5:** Locate the deflector mounting brackets (#12304). Using a screwdriver, slightly pry the bracket open and insert over each end of the deflector frame.



# **DEFLECTOR KIT**

#### MODEL # 60600

#### ASSEMBLY INSTRUCTIONS

**Step 6:** Locate on the spreader the cross-bar lock nuts. Remove the locknuts and place the deflector bracket over the bolt. The deflector bracket has a c-shaped section that will fit flush on the end of the spreader stand (black bent hoop bar).

**Step 7:** Re-install each lock nut through the deflector mounting bracket so that the deflector will now be attached to the 90950 spreader.

**Step 8:** Adjust deflector so that side panels have proper clearance from tires throughout panel rotation. To increase clearance, slide wire deflector frame through the guide in the deflector mounting clamp ears.





### TO ATTACH DEFLECTOR TO 2150,2170,90399 or 90365 SPREADERS

**Step 5:** Mount round frame clamps (# 12305) on deflector frame in the orientation shown. Leave bolts (#36210) and locknuts (# 36330) marked by arrows loose. This will allow you to split bracket and slide deflector bracket over frame of spreader and clamp tight.



### **DEFLECTOR KIT**

#### MODEL # 60600

# ASSEMBLY INSTRUCTIONS

**Step 6:** Slide bracket over frame of spreader.

**Step 7:** Adjust location of clamps so that deflector panels can be rotated past wheels. Hand tighten all bolts (#36210) and locknuts (# 36330). Do not use an impact wrench.



## **CUSTOMER SERVICE**

574.848.7491 | SUPPORT@EARTHWAY.COM | www.EARTHWAY.com | 1009 Maple Street, Bristol, IN 46507

# **ONE YEAR WARRANTY**

The manufacturer warrants this product free of defects in original workmanship and materials for a period of one year to the end user with the original purchase receipt. If a manufacturing non-conformance is found, the manufacturer. at its discretion will repair or replace the part(s)/product at no charge provided the failure is not the result of incorrect installation, mishandling, misuse, tampering, or normal wear and tear as determined by the manufacturer.

The manufacturer at its discretion may require that the part(s) or product be returned along with the original purchase receipt for examination and compliance with the terms of this warranty. Do not return any product without first receiving authorization. To seek remedy under this warranty, contact the manufacturer at 574-848-7491, or write 1009 Maple Street, Bristol, IN 46507 and describe the nature of the manufacturing defect. SPECIFIC LIMITATIONS: This warranty covers only the part(s) or product; any labor charges associated with repair or replacement of non-conformances are specifically excluded. Due to the corrosive nature of most fertilizers and ice melt products, the manufacturer makes no warranty against and specifically excludes part(s) or product degradation or failure due to corrosion or its effects.